COMPETENCY ANALYSIS PROFILE TRUCK AND COACH TECHNICIAN 310T

(All unshaded skill sets must be demonstrated/completed)

SKILL SETS SKILLS

OCCUPATIONAL HEALTH AND SAFETY PROCEDURES	Identify potential workplace health and safety hazards	Handle, store and dispose of hazardous materials	Wear and maintain personal protective equipment	Comply with workplace-related legislation	Interpret and apply service- related information
U5135.0	5135.01	5135.02	5135.03	5135.04	5135.05
	Practice good housekeeping in workplace	Comply with WHMIS guidelines			
	5135.06	5135.07			
ELECTRICAL SYSTEMS - STARTING AND CHARGING	Perform visual inspection	Diagnose and troubleshoot starting systems and components	Repair starting systems and components	Verify and document repair of starting system and components	Diagnose and troubleshoot charging systems and components
U5136.0	5136.01	5136.02	5136.03	5136.04	5136.05
	Repair charging system and components	Verify and document repair of charging system and components			
	5136.06	5136.07			
ELECTRICAL SYSTEMS - BODY ELECTRICAL	Perform visual inspection	Diagnose and troubleshoot body electrical systems and components	Repair body electrical systems and components	Verify and document repair of body electrical systems and components	Repair system warning devices
U5137.0	5137.01	5137.02	5137.03	5137.04	5137.05
	Verify and document repair of system warning devices	Diagnose and troubleshoot fire suppression systems and components	Repair fire suppression systems and components	Verify and document repair of fire suppression systems and components	Repair coach destination signs
	5137.06	5137.07	5137.08	5137.09	5137.10
	Verify and document repair of coach destination signs	Diagnose and troubleshoot supplemental restraint systems (SRS) and components	Repair supplemental restraint systems (SRS) and components	Verify and document repair of supplemental restraint systems (SRS) & components	
	5137.11	5137.12	5137.13	5137.14	

TRUCK AND COACH TECHNICIAN

FUEL SYSTEMS	Perform visual inspection	Diagnose and troubleshoot fuel systems and components	Repair fuel systems and components	Verify and document repair of fuel systems and components	
U5138.0	5138.01	5138.02	5138.03	5138.04	
ENGINE SYSTEMS	Perform visual inspection	Diagnose and troubleshoot cooling systems and components	Repair cooling systems and components	Verify and document repair of cooling systems and components	Diagnose and troubleshoot engine lubricating systems and components
U5139.0	5139.01	5139.02	5139.03	5139.04	5139.05
	Repair engine lubricating systems and components	Verify and document repair of engine lubricating systems and components	Diagnose and troubleshoot cylinder head and components	Repair cylinder heads and components	Verify and document repair of cylinder head and components
	5139.06 Diagnose and troubleshoot engine block and components	S139.07 Repair engine block and components	Verify and document repair of engine block and components	Diagnose and troubleshoot auxiliary coolers and components	S139.10 Repair auxiliary coolers and components
	5139.11 Verify and document repair of auxiliary coolers and components 5139.16	5139.12	5139.13	5139.14	5139.15

ENGINE MANAGEMENT SYSTEMS U5140.0	Perform visual inspection 5140.01	Diagnose and troubleshoot fuel control systems and components	Repair fuel control systems and components	Verify and document repair of fuel control systems and components	Diagnose and troubleshoot electronic ignition systems and components
03140.0	Repair electronic	5140.02 Verify and	5140.03 Diagnose and	5140.04	Verify and document
	ignition systems and components	document repair of electronic ignition systems and components	troubleshoot electronically- controlled engine systems and components	Repair electronically- controlled engine systems and components	repair of electronically- controlled engine systems and components
	5140.06	5140.07	5140.08	5140.09	5140.10
	Perform engine tune-ups				
	5140.11				
EXHAUST, INTAKE, AND EMISSION CONTROL SYSTEMS	Perform visual inspection	Diagnose and troubleshoot exhaust, intake, and emission control systems and components	Repair exhaust, intake, and emission control systems and components	Verify and document repair of exhaust, intake, and emission control systems and components	Diagnose and troubleshoot turbocharger systems and components
U5141.0	5141.01	5141.02	5141.03	5141.04	5141.05
	Repair/Replace turbocharger systems and components	Verify and document repair of turbocharger systems and components			
TRANSMISSION	5141.06 Perform visual	5141.07 Diagnose and	Repair/Replace	Verify and	Diagnose and
SYSTEMS	inspection	troubleshoot clutch systems and components	clutch systems and components	document repair of clutch systems and components	troubleshoot manual systems and components
U5142.0	5142.01	5142.02	5142.03	5142.04	5142.05
	Repair manual systems and components	Verify and document repair of manual transmissions and components	Diagnose and troubleshoot automatic/automat ed transmission systems and components	Repair/Replace automatic/ automated transmission systems and components	Verify and document repair of automatic/ automated transmission systems and components
	5142.06	5142.07	5142.08	5142.09	5142.10

	erform visual spection	Diagnose and troubleshoot drive shafts, drive axle assemblies and components	Repair/Replace drive shafts, drive axle assemblies and components	Verify and document repair of drive shafts, drive axle assemblies and components	
U5143.0	5143.01	5143.02	5143.03	5143.04	
	erform visual spection	Diagnose and troubleshoot frames, hitching systems, and components	Repair frames and hitching systems and components	Verify and document repair of frames, hitching systems and components	
U5144.0	5144.01	5144.02	5144.03	5144.04	
	erform visual spection	Diagnose and troubleshoot body and/or trim	Repair body and/or trim	Verify and document repair of body and/or trim	
U5145.0	5145.01	5145.02	5145.03	5145.04	
	erform visual spection	Diagnose and troubleshoot suspension systems and components	Repair suspension system and components	Verify and document repair of suspension systems and components	
U5146.0	5146.01	5146.02	5146.03	5146.04	
	erform visual spection	Diagnose and troubleshoot steering systems and components	Repair/Replace steering systems and components	Verify and document repair of steering system and components	Align steering and axles
U5147.0	5147.01	5147.02	5147.03	5147.04	5147.05
DIRAC AND LILIDS	erform visual spection	Diagnose and troubleshoot tires, wheels, rims, hubs, and components	Repair tires, wheels, rims, hubs and components	Verify and document repair of tires, wheels, rims, hubs and components	
U5148.0	5148.01	5148.02	5148.03	5148.04	
	erform visual spection	Diagnose and troubleshoot air supply systems and components	Repair/Replace air supply system and components	Verify and document repair of air supply system and components	Diagnose and troubleshoot auxiliary air components
				'	

TRUCK AND COACH TECHNICIAN

	Repair/replace auxiliary air components 5149.06	Verify and document repair of auxiliary air components			
BRAKING SYSTEMS	Perform visual inspection	Diagnose and troubleshoot brake system (air or hydraulic)	Repair brake system (air or hydraulic)	Verify and document repair of brake system (air or hydraulic)	Resurface brake drums, lines and rotors
U5150.0	5150.01	5150.02	5150.03	5150.04	5150.05
HEATING, VENTILATION, AIR CONDITIONING (HVAC) & REFRIGERATION SYSTEMS	Perform visual inspection	Diagnose and troubleshoot HVAC systems and components	Repair HVAC systems and components	Verify and document repair of HVAC systems and components	Diagnose and troubleshoot refrigeration systems and components
U5151.0	5151.01	5151.02	5151.03	5151.04	5151.05
	Repair refrigeration systems and components	Verify and document repair of refrigeration systems and components			
HYDRAULIC SYSTEMS	Perform visual inspection	Diagnose and troubleshoot hydraulic systems and components	Repair hydraulic systems and components	Verify and document repair of hydraulic systems and components	
U5152.0	5152.01	5152.02	5152.03	5152.04	